

# IMPORTANT SAFETY TIPS

- **HIGH PRESSURE CYLINDER** – Always secure cylinder. Check cylinder pressure upon receipt of cylinder to confirm it is full. A full cylinder should gauge at 2000 psi. Remember to mark cylinder when empty.
- **CYLINDER VALVE** – Always turn the cylinder valve off when the cylinder is not in use as this will prolong the life of your regulator.
- **REGULATOR** – Visually check O ring on stem of regulator for wear with each cylinder change to prevent helium loss. (the O ring is usually the only failed part of regulator – replace as necessary).
- **HELIUM** – Helium is a nontoxic, odorless, colorless, nonflammable gas stored in cylinders at high pressure. It can cause rapid suffocation when inhaled.
- **BALLOONS** – Do not place balloons near heat or A/C vents. Helium expands and contracts rapidly. To boost sales, be sure balloons are properly inflated at all times.

REORDER HELIUM WHEN GAUGE READS 500 PSI

**Fax Your Orders to:**  
**(585) 473-4062**

